

# FRONT WHEEL SETUP

Front Axle Pin



1. Locate the front axle pin
2. Attach the pin loosely to the front wheel
3. Mount the front wheel to the frame
4. Hand tighten nut
5. Close the quick release clamp

Rear Fender

Front Fender



# FENDER SETUP

Your Defiant Ebike comes with optional front and rear fenders. Follow these steps for installation

1. Build the rear and front fenders as shown. There will be extra / unused parts
2. Unscrew the headlight
3. Position the front fender bracket so the slots align with the bolt hole from the headlight
4. Reattach the headlight and front fender using the original headlight bolt
5. Attach the rear fender to the seat pole
6. Go riding through muddy puddles

